

ON-POINT & TOUCH-POINT ASSEMBLY INSTRUCTIONS

(2) ON-POINT VOLLEYBALL BOXES

1. 34" X 32" X 4"
2. 67" X 7" X 2"

*(1) TOUCH-POINT ACCESSORY BOX

39" X 19" 2"

PLEASE READ ALL INSTRUCTIONS BEFORE OPERATING THIS APPARATUS

- TO INCREASE LONGEVITY, PLEASE USE 25LB WEIGHT
- PLEASE USE IN A CONTROLLED SETTING
- DO NOT USE THIS APPARATUS FOR ANYTHING OTHER THAN ITS INTENDED PURPOSE

TOOLS NEEDED



(1) ADJUSTABLE WRENCH


SET INCLUDES:



(1) VERTICAL INNER POLE (SILVER)




(1) VERTICAL OUTER POLE (YELLOW)



(1) BASE



(5) NUTS



(16) VELCRO



(3) 3.5" BOLTS
(2) 3.2" BOLTS



(1) 20" HOOP



(1) 30" HOOP



(1) TEMPO TARGET HEAD



(1) ANGLE WHEEL




(2) NETS




OPTIONAL ACCESSORY
(1) TOUCH-POINT


MANUAL AND ASSEMBLY INSTRUCTIONS





1. INSERT SILVER INNER PRE-DRILLED POLE INTO YELLOW OUTER POLE
2. VERTICALLY PLACE ASSEMBLED POLE ON THE BASE



3. LINE UP OUTERMOST PRE-DRILLED HOLE OF THE BASE WITH OUTERMOST PRE-DRILLED HOLE OF THE YELLOW POLE
4. SECURE POSITION BY SCREWING (3) 3.5" BOLTS AND (3) NUTS THROUGH BASE AND POLES



5. ATTACH ANGLE WHEEL BY LINING UP SILVER INNER POLE WITH OUTERMOST HEAD OF THE ANGLE WHEEL
6. FASTEN WITH (2) 3.2" BOLTS AND (2) NUTS.



7. INSERT THE NECK OF THE ANGLE WHEEL INTO THE TARGET HEAD OF YOUR CHOICE
*FOR FURTHER INSTRUCTION FOR TOUCH-POINT ATTACHMENT, PLEASE PROCEED TO THE NEXT PAGE
8. LINE THE PRE-DRILLED HOLES WITH THE LATCH PIN




9. SET DESIRED ANGLE WITH A LATCH PIN
10. ATTACH THE NET TO THE RIM OF THE HOOP BY USING 8 VELCRO STRAPS



11. CORRECT POSITIONING FOR THE METAL REINFORCEMENT PLATE ON 20" AND 30" TARGETS
SHOULD ALWAYS BE FACE DOWN ON THE RIM.

ALTERNATE ASSEMBLY INSTRUCTIONS FOR TOUCH-POINT



8. SET THE ANGLE STRAIGHT UP WITH A LATCH PIN



9. SET TOUCH-POINT ON THE 5TH HOLE (THERE SHOULD BE 4 HOLES SHOWING UP TOP) TO REACH 11 FT TALL.



10. CORRECT POSITIONING FOR THE METAL REINFORCEMENT PLATE ON 20" AND 30" TARGETS SHOULD ALWAYS BE FACE DOWN ON THE RIM.

END OF DOCUMENT